Quick


SANYO

Start


FWDV225F



Accessories



Basic DVD/VCR Connection




VCR Head Cleaning



	DVD	VCR
Playback	✓	✓
External Tuner Recording	_	*
DVD → VCR Recording	-	-
VCR → DVD Recording	_	_
Built in TV Tuner	_	_

Recording

This unit has no tuner system so it cannot receive TV broadcasts without an RF Modulator, external tuner or such devices.



Press on to turn On the unit. Then insert a recordable tape.



- Press to switch to the VCR mode.
- Press until "L1" or "L2" is displayed on the TV screen. Select "L1" to activate rear input jacks. Select "L2" to activate front input jacks.
- Press to select the desired tape speed.

Tape speed	Recording / playback time		
Type of tape	T60	T120	T160
SP mode	1hour	2hours	2-2/3hours
SLP mode	3hours	6hours	8hours

repeatedly until desired recording duration is selected.



- To stop recording temporarily, press
- to stop recording. Press

to eject the recorded cassette tape.

Need help?

Owner's Manual For assistance with setup please check the Owner's Manual, that came with the unit.

Online Support Go to: sanyo-av.com

Phone Support Call 1-866-212-0436 for our customer support.

SANYO is a registered trademark of SANYO Electric Co., Ltd. and is used by Funai Electric Co., Ltd. and Funai Corporation, Inc. under license from SANYO Electric Co., Ltd.

Any liability related to SANYO products, including design and quality, is the sole responsibility of Funai Electric Co., Ltd. and Funai Corporation, Inc. Please contact Funai Corporation, Inc. for any questions or claims related to SANYO products: 1 866 212 0436 sanyo-av.com





Printed in China E8R6BUH

2VMN00193 ★★★★