

Language Select (Player Menu)





Need help?

Owner's Manual

See the owner's manual that came with the main unit.

Online

www.funaiamerica.com



© 2010 Funai Electric Co., Ltd.

Printed in China X6500UD 1VMN30094B ★★★




Quick Start Guide






PB750FX1






Guide to Buttons on the Display Unit



1	STANDBY/ON	On / Off the unit
2	OPTION	Displays option menu
3	► (play)	Start or resume playback
4	■ (stop)	Stop playback
(5)	(previous)	Skip to previous title, chapter, track or file
6	► (next)	Skip to next title, chapter, track or file
7	VOL	Decrease volume level
8	VOL.+	Increase volume level
9	▲/ ▼/ ⋖ /►	Select items or settings
	ОК	Confirm or select items

Wireless Connection



Network Operations

To use the network features, you must visit the following websites on your PC and create accounts to rent or buy movies / TV episodes and watch them streamed instantly via the Internet.



Visit netflix.com/FUNAI




Visit www.cinemanow.com/Login



Visit www.blockbuster.com/auth/login



No accounts needed for vTuner



Note

- Please confirm the encrypted format and SSID by your wireless device's user manual.
- Please confirm your wireless router is updated with the latest software.
- Please make sure your wireless router and network connectivity with other devices (such as a computer) is working.
- If the several network access points are found in searching the wireless network, select the one in current use.

Need help?

Owner's Manual

See the owner's manual that came with the main unit.

Online

Go to: www.funaiamerica.com

Hotline


Call 1-877-39-Funai (1-877-393-8624) for our operators.



© 2010 Funai Electric Co., Ltd.

Wireless Network Connection Guide





Printed in China
1VMN30393 *****





